




### PITCH ANTENNA CIRCUIT




### VARIABLE PITCH OSCILLATOR




### FIXED PITCH OSCILLATOR




### PITCH TUNING





### VOLUME ANTENNA CIRCUIT




### VOLUME OSCILLATOR



### VOLUME TUNING




### FRONT PANEL




### POWER CONNECTOR

14 VAC @ 200mA


### POWER SUPPLY




### VOLTAGE CONTROLLED AMPLIFIER



### DETECTOR



### VCA PROCESSOR



Etherwave Theremin Schematic Diagram

Updated by R. Hess 1/05/2018 based on 11-211J board version.